

# ELECTRICITY METERS

Ferraris meters



Deutsche Zählergesellschaft

## Single phase meter / 3 & 4-wire balanced loads

		direct connection			transformer connection		transformer connection balanced loads			
		W603U	W624U	W626U	MW601U	MW602U	4-wire	3-wire		
type		W603U	W624U	W626U	MW601U	MW602U	MW601U/V	MW602U/V	MW601U/D	MW602U/D
class		2	2	2	2	2				
rated voltage range	V	110-250	220-230	220-230	58-250	58-250	3x58/100- 3x260/450	3x110/190- 3x260/450	3x100- 3x500	3x100- 3x500
basic (max.) current	A	10(30)	10(40)	10(60)	1	1(2)	1	1(2)	1	1(2)
					5	5(10)	5	5(10)	5	5(10)
maximum load	%I <sub>N</sub>	300	400	600	125	200	125	200	125	200
power loss/phase in voltage circuit at U <sub>N</sub>	VA	4.2	4.2	4.1	4.2	4.2	4.2	4.2	4.2	4.2
	W	0.9	0.9	0.9	0.9	0.9	0.9	0.9	0.9	0.9
power loss/phase in current circuit at I <sub>N</sub>	VA	0.4	0.3	0.3	0.3	0.3	0.3	0.3	0.3	0.3
	W									
weight of meter	kg	1.4	1.4	1.4	1.4	1.4	1.4	1.4	1.4	1.4

Table of the most common versions, other versions on request.

## Transformer-operated polyphase meters

		4-wire connection					3-wire connection			
type		MDV601U	M1DV601U	MDV602U	MDV616U	M1DV626U	MDD601U	M1DD601U	MDD602U	MDD616U
class		2	1	2	2	1	2	1	2	2
rated voltage range	V	3x58/100- 3x260/450	3x58/100- 3x260/450	3x58/100- 3x260/450	3x58/100- 3x400/690	3x58/100- 3x260/450	3x100- 3x660	3x100- 3x660	3x100- 3x660	3x100- 3x660
basic (max.) current	A	1	1	1(2)	5    1	5    1	1	1	1(2)	5    1
		5	5	5(10)	5	5	5	5	5(10)	5
maximum load	%I <sub>N</sub>	125	125	200	125*	125*	125	125	200	125*
power loss/phase in voltage circuit at U <sub>N</sub>	VA	3.8	3.2	3.8	3.8	3.8	3.8	3.2	3.8	3.8
	W	0.7	0.7	0.7	0.7	0.8	0.7	0.7	0.7	0.8
power loss/phase in current circuit at I <sub>N</sub>	VA	0.5	0.5	0.5	1.4 (5A)	0.04 (1A) 1.2 (5A)	0.5	0.5	0.5	1.4 (5A)
	W									
weight of meter	kg	3.3	3.3	3.3	3.3	3.3	2.8	2.8	2.8	2.8

\*) with reference to 5A

Table of the most common versions, other versions on request.

## Whole current polyphase meters

		4-wire connection					3-wire connection	
type		DV603U	DV604U	DV615U	DV616U	DV628U	DV620U	DD626U
class		2	2	2	2	2	2	2
rated voltage range	V	3x110/190-3x260/450	3x110/190-3x260/450	3x220/380-3x230/400	3x220/380-3x230/400	3x220/380-3x230/400	3x220/380-3x230/400	3x190-3x660
basic (max.) current	A	10(30)	10(40)	20(100)	10(60)	5(40) 10(80)	5(50) 10(100)	10(60) 20(120)
maximum load	%I <sub>N</sub>	300	400	500	600	800	1000	600
power loss/phase in voltage circuit at U <sub>N</sub>	VA	3.5	3.5	4.8	4.9	5.3	5.3	4.8
	W	0.8	0.8	0.9	0.9	1.1	1.2	1.1
power loss/phase in current circuit at I <sub>N</sub>	VA	0.15	0.15	0.18	0.1	0.1	0.1	0.1
	W							
weight of meter	kg	3.2	3.2	3.85	3.3	3.3	3.3	2.8
						3.85	3.85	3.35

Table of the most common versions, other versions on request.


## Type scheme for Ferraris meters

1	2	3	4	5	6	7	8	9	
M									Meter for direct connection
M1									transformer operated meter
	B								transformer operated meter class 1*
		DV							active energy meter
		DD							reactive energy meter
		W							4-wire connection meter
			60						3-wire connection meter
			61						single phase meter
			62						series 60
				1					series 61
				2					series 62
				3					load factor 125%
				4					load factor 200%
				5					load factor 300%
				6					load factor 400%
				8					load factor 500%
				0					load factor 600%
					U				load factor 800%*
					U2				load factor 1000%*
						T			magnetic bearing
						T3			double jewel bearing
						T4			special bearing for difficult environments*
							F		single tariff
							F2		double tariff
							F3		three tariff*
							F6		import-export meter*
								R	electronic S0 pulse device
									pulse device (Reed contact)
									S0 pulse device with electronic reverse running brake*
									S0 pulse device with pulse value adjustment*
									reverse-running brake


e.g. MBDV616UTFR means transformer-operated meter (M), for reactive energy (B), 3-phase, 4-wire system (DV), series 61, admissible load factor 600% I<sub>N</sub> (.6) with reference to 1A, double jewel bearing (U), two-tariff register (T), pulse device (F), reverse-running brake (R)

\*) not available for single-phase meters


## Dimensions of meters in the 60/61/62 series




**(M)W6..**




**(M)W6.. for switch board mounting.**  
The dimensions for the cut-out in  $\bigcirc$




**(M)DD6../(M)DV6..**  
Case for 60A max.



**(M)DD6../(M)DV6.. for switch board mounting.**  
Case for 60A max. The dimensions for the cut-out in  $\bigcirc$



**DD6../DV6..**  
Case for >60A. Current connection  $\varnothing 11$ mm.



**DD6../DV6..**  
Case for >60 A. Current connection  $\varnothing 9.5$  mm.



**Deutsche Zählergesellschaft mbH**

Michael-Welte-Str. 5-39, 78147 Vöhrenbach

Tel. 07727-9263-0

Fax 07727-9263-99

Vertriebsbüro

Bachstraße 9-17 · 22083 Hamburg · Tel. 040/2 26 52-0

Fax 040/2 26 52-199